DRIVETRAIN › QUICK CHANGE DIFFERENTIALS AND COMPONENTS › TORQUE BALLS HOUSINGS AND COMPONENTS

Torque Ball Boot

Rubber · Torque Ball Assembly

PART NUMBER
TIP4728
View on PriceGuidePro ›



OVERVIEW

The torque ball boot seals the joint against dirt and retains lubricant, protecting a component that is expensive to replace. A split boot lets grit into the ball and destroys it quickly. Rubber construction flexes through the full range of driveline movement.

Boots are inspected regularly and replaced at the first sign of cracking.

Torque Ball Boot, Rubber, Torque Ball Assembly. Sold each.

SPECIFICATIONS

Material	**Rubber**
Style	**Torque Ball Assembly**
Sold As	**Each**

SHIPPING & PACKAGING

Package	**6.05 × 5.9 × 2.7 in**
Ship Weight	**0.13 lb**
Country of Origin	**USA**
Vehicle Type	**Car**

⚠ WARNING: Cancer and Reproductive Harm — www.P65Warnings.ca.gov