



Stack Stands

SAFETY INSTRUCTIONS

WARNING:

NEVER EXCEED RATED CAPACITY OF STACKSTANDS
STEEL SAFE LOAD LIMIT DO NOT EXCEED 3,000 LBS. PER STAND

1. Read all instructions completely and fully understand before using stackstands.
2. Do not use stackstands on unlevel surfaces or rough, unlevel ground.
3. Always make sure load is centered on stackstand cross member.
4. Never slide or move a load while it is resting on stackstand.
5. Always use stackstands in upright position.
6. Never place a load on stackstands when two or more have been stacked together.
7. Never place stackstands on rollers, wheels or any other form of platform that has wheels or rollers.

Failure to follow these warnings may result in personal injuries and/or property damage.



Allstar Performance 8300 Lane Dr., Watervliet, MI 49098
Phone: (269) 463-8000 Fax: (800) 772-2618 www.allstarperformance.com